



Low pass VOL pot series resistance / Ccable1 (increasing with lowering of volume)

parallel wiring of lower half of Volume pot with Zin1 yields dramatically exaggerated fast drop in volume and unnatural control feeling

Low pass VOL pot series resistance / Ccable2 (increasing with lowering of volume)

tube amp drive impedance yields reduced dampening for low frequencies, perceived as bass boost and loose response

Permission refused for serving / posting this file from any site other than <http://aquataur.guru>

Title Typical vintage sound chain		
Size A4	Number	Revision 1.0
Date: 14.03.2021	Sheet of 1/1	
File: D:\projekte\...\blockschaltbild vintage sound chain BCB		